

QUICKSAND

FLAT FINISH COATING SYSTEM

Acrylic



DESCRIPTION	ACRYLIC QUICKSAND provides a render appearance half way between a fine flat texture coating and a smooth scrub fine render finish, similar to its sister coating (polymer modified mineral coating) only exhibiting greater flexibility.
SUITABLE FOR	<ul style="list-style-type: none"> • Hebel Products • AC Sheeting • Hardies Fibre Cement Sheeting
APPLICATION	<ol style="list-style-type: none"> 1. Apply QW PRIMER. 2. Flush and set all joints with QW Jointing Compound. 3. While wet place 50mm wide alkali resistant QUICKCLAD mesh over joints. Trowel additional Jointing Compound over reinforcing mesh, feather out and allow to dry to a flat finish. 4. <u>Option to rectify undulation on substrate</u> It is preferred by Quickwall that an application of regular SKIMCOAT at 2:1 polymer be applied over substrate and joints prior to finish coat. 5. Apply ACRYLIC QUICKSAND. 6. Apply 2 coats of QW AQUASEAL. <p>All surface areas must be clean and free of dust, oil, loose or fretting mortar. (See spec sheets on 'Coating Application for New and Existing Cement Sheeting' and 'Jointing Compound'.)</p>
Uneven Substrates	The base coat generally used on uneven surface is Quickwall HIGH-BUILD (a two pack polymer modified mineral system) to build up obscure and defective substrates.
	For exterior applications it is recommended to coat with two coats of Quickwall AQUASEAL 100% acrylic membrane paint to complete the system and complete the waterproofing attributes.
SPECIAL FEATURES	This product has excellent biocides to protect against microbial attack and excellent bond to most properly prepared substrates.
NOTE	Environment friendly with very low VOC and very applicator friendly.
APPROVED FOR	Government Projects, Defence Housing Authority, Commercial and Domestic applications.
GUARANTEE	Seven years when applied by an Approved Applicator and in accordance to Quickwall specification.
SPECIFICATION	<p>1st Coat: Apply Quickwall PRIMER</p> <p>2nd Coat: Apply Quickwall SKIMCOAT (recommended)</p> <p>3rd Coat: Apply Quickwall ACRYLIC QUICKSAND</p> <p>4th Coat: Apply 1 coat of AQUASEAL membrane paint</p> <p>5th Coat: Apply 1 coat of AQUASEAL membrane paint</p>